



Repairing RIM Blackberry 8700c Sticking Click Wheel

Tools used in this guide

- [T6 Torx Screwdriver](#)



Step 1 - installation New on/off and mute buttons

- To remove the back cover, push down on the button and slide the cover towards the bottom of the phone.
- To remove the battery, use your fingernail to pull upward on the top notch of the battery.



Step 2

- You can see that there are four T6 Torx screws securing the back half of the casing.
- Unscrew all four screws and then gently pull the two halves of the casing apart, being careful to watch for parts that fall.



Step 3

- After pulling apart the back casing, you will see four more T6 Torx screws that require removing before you can gain access to the internal parts of the phone.
- Remove these screws the same way you did the previous 4 and set them aside.



Step 4

- Once these final 4 screws are removed, lift the black casing away from the phone and set aside. A side bar piece will fall away with this action, set it aside as well.
 - To remove the front cover, simply pull it away from the main electronics board.
- The click wheel is now exposed.
 - Be sure to check if there is any sand or small rocks preventing the moving of the wheel.
- Clear out all loose debris and use a cotton swab or similar tool to clean completely around the wheel.

